

Packing instruction Trolley Carbon



Arrange the individual parts as shown in the photo. There are 2 white foam blocks under the shaft support. There is cardboard between the wheels. The front wheel with rod is at the bottom and even capture with some white foam pads so that it will not slide.



Now fill the box with the 2 small boxes. The battery, charger and scorecard in one box holder. Plastic bag on front wheel so that it doesn't come up.



Place the long piece of foam as on the photo. Fold the bag and over the wheels to lay.

Cover the long piece of foam as on the photo. Fold the bag and over the wheels to lay.

Cover and glue well with tape.

stick the shipping ticket well and then the box is ready for shipment.